

Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tool needed : Screwdriver (not provider).


PART LIST		
ITEM	DESCRIPTION	QTY
A	NIGHTSTAND	1 PC
B	LEG	4 PCS
C	HANDLE	2 PCS
D	HANDLE SCREW	4 PCS
E	FLAT WASHER	4 PCS
F	DRAWER	2 PCS

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 x 20mm 	8 PCS
2	M6 FLAT WASHER 	8 PCS
3	M6 SPRING WASHER 	8 PCS
4	M4 ALLEN KEY (BALL SHAPE) 	1 PC


STEP 1

Note:

Open the last of drawer and take out all the parts.



STEP 2




ASSEMBLY INSTRUCTIONS

2 of 2

STEP 3

Note :
Hold the handle flat and
then tighten the screws



STEP 4

